USB WiFi Conflicts

If you use a USB WiFi connector to access the internet, it can possibly become disconnected when using the Memor-ease / ImageBox units

Some examples of these type of devices

To rectify this simply unplug your USB WiFi connector and re-connect it this will cause it to re-initialize and become active again

Known device to have this problem is the Belkin **Wireless G adapter F5D7050**